

# Fluorocarbon/Nylon String Chart for 38 String “Delight” Heartland Harp

---

1-----	.025 Nylon-----	C - RED
2-----	.025 Nylon-----	B
3-----	.025 Nylon-----	A
4-----	.025 Nylon-----	G
5-----	.028 Nylon-----	F - BLUE
6-----	.028 Nylon-----	E
7-----	.028 Nylon-----	D
8-----	.032 Nylon-----	C - RED
9-----	.032 Nylon-----	B
10-----	.032 Nylon-----	A
11-----	.032 Nylon-----	G
12-----	.036 Nylon-----	F - BLUE
13-----	.034 FC -----	E
14-----	.034 FC -----	D
15-----	.036 FC -----	C - RED
16-----	.036 FC -----	B
17-----	.036 FC -----	A
18-----	.040 FC -----	G
19-----	.040 FC -----	F - BLUE
20-----	.043 FC -----	E
21-----	.043 FC -----	D
22-----	.048 FC -----	Middle C - RED
23-----	.048 FC -----	B
24-----	.053 FC -----	A
25-----	.056 FC -----	G
26-----	.058 FC -----	F - BLUE
27-----	.058 FC -----	E
28-----	.066 FC -----	D
29-----	.068 FC -----	C - RED
30-----	#30 - Fibercore-----	B
31-----	#31 - Fibercore-----	A
32-----	#32 - Fibercore-----	G
33-----	#33 - Fibercore-----	F - BLUE
34-----	#34 - Fibercore-----	E
35-----	#35 - Fibercore-----	D
36-----	#36 - Fibercore-----	C-RED
37-----	#37 - Fibercore-----	B
38-----	#38 - Fibercore-----	A

**IMPORTANT NOTE:** Please do not put strings other than the ones designated above on your harp. To do so may cause severe stress on your soundboard, and lead to damaging your harp!

To re-order strings, call Vermont Strings at 1-802-244-8564. Nylon strings should be changed every 1-2 years, and metal strings should be changed every 3-5 years.