

Fluorocarbon/Nylon String Chart for 38 String “Delight” Heartland Harp

1	.025 Nylon	C-RED
2	.025 Nylon	B
3	.025 Nylon	A
4	.025 Nylon	G
5	.025 Nylon	F
6	.025 Nylon	E
7	.028 Nylon	D
8	.028 Nylon	C-RED
9	.032 Nylon	B
10	.032 Nylon	A
11	.027 FC	G
12	.027	F
13	.027	E
14	.028	D
15	.034	C-RED
16	.034	B
17	.034	A
18	.036	G
19	.036	F
20	.038	E
21	.038	D
22	.044	Middle C-RED
23	.044	B
24	.056	A
25	.056	G
26	.059	F
27	.059	E
28	.067	D
29	.070	C-RED
30	.070	B
31	.020/5/.008x36 SFB	A
32	.020/6/.008x37.5 SFB	G
33	.020/5/.010 x39. SFB	F
34	.022/6/.010 x40.5 SFB	E
35	.022/6/.012 x 42.25 SFB	D
36	.024/5/.015 x44. SFB	C-RED
37	.026/5/.015 x 45.625 SFB	B
38	.026/10/.015 x 47 SFB	A

IMPORTANT NOTE: Please do not put strings other than the ones designated above on your harp. To do so may cause severe stress on your soundboard, and lead to damaging your harp!
To re-order strings, call Vermont Strings at 1-802-244-8564. Strings should be changed every 1-2 years.